




HONDA MOTOR CO., LTD.

31ME5620
00X31 ME5-6200

UI©3009705F
PRINTED IN USA

1985 HONDA

**NIGHTHAWK
650**



**CB650SC
OWNER'S MANUAL**

IMPORTANT NOTICE

• OPERATOR AND PASSENGER

This motorcycle is designed to carry the operator and one passenger. Never exceed the vehicle capacity load as shown on the tire information label.

• ON-ROAD USE

This motorcycle is not equipped with a spark arrester and is designed to be used only on the road. Operation in forest, brush, or grass covered areas may be illegal. Obey local laws and regulations.

• READ THIS OWNER'S MANUAL CAREFULLY

Pay special attention to statements preceded by the following words:

⚠ WARNING

Indicates a strong possibility of severe personal injury or loss of life if instructions are not followed.

CAUTION:


Indicates a possibility of personal injury or equipment damage if instructions are not followed.

NOTE: Gives helpful information.

This manual should be considered a permanent part of the vehicle and should remain with the vehicle when resold.

HONDA NIGHTHAWK 650 CB650SC OWNER'S MANUAL

1985



All information in this publication is based on the latest product information available at the time of approval for printing. HONDA MOTOR CO., LTD. reserves the right to make changes at any time without notice and without incurring any obligation. No part of this publication may be reproduced without written permission.

© Honda Motor Co., Ltd. 1984

CONTENTS

	Page		Page
MOTORCYCLE SAFETY	1	Front Wheel Removal	46
Safe Riding Rules	3	Rear Wheel Removal	49
Protective Apparel	4	Fuse Replacement	51
Modifications	5	MAINTENANCE	53
Loading and Accessories	6	Maintenance Schedule	55
Tubeless Tires	8	Maintenance Record	57
Suspension	10	Engine Oil and Filter	58
DESCRIPTION	14	Spark Plugs	60
Parts Location	14	Air Cleaner	61
Serial Numbers	18	Idle Speed	62
Parts Function	20	Crankcase Breather	63
Fuel	28	Final Drive Oil	64
Engine Oil	30	Clutch	65
Final Drive Oil	32	Front Brake	66
OPERATION	33	Rear Brake	68
Pre-ride Inspection	33	Side Stand	70
Starting the Engine	34	Battery	71
Break-in	37	CLEANING	73
Riding	38	STORAGE GUIDE	74
Braking	41	EMISSION CONTROL SYSTEM	76
Parking	42	CONSUMER INFORMATION	78
Anti-theft Tips	43	SPECIFICATIONS	79
SPECIAL PROCEDURES	44	WARRANTY SERVICE	84
Tool Kit	45		

WELCOME

Your new motorcycle presents you with an invitation to adventure and a challenge to master the machine. Your safety depends not only on your own alertness and familiarity with the motorcycle, but also the motorcycle's mechanical condition. A pre-ride inspection before every outing and regular maintenance are essential.

To help meet the challenges safely and enjoy the adventure fully, become thoroughly familiar with this Owner's Manual **BEFORE YOU RIDE THE MOTORCYCLE**. Also, for your own and your Honda's sake, please read all the written material which came with your new Honda. These items include:

- *Honda Owner's Identification Card
- *Set-up and Predelivery Checklist
- *Honda Motorcycle Emission Control System, Distributor's Warranty
- *Honda Motorcycle, Distributor's Limited Warranty
- *Honda Motorcycle Noise Control Systems, Distributor's Warranty

When service is required, remember that your Honda dealer knows what it takes to keep your Honda going strong. If you have the required mechanical "know-how" and tools, your dealer can supply you with an official Honda Shop Manual to help you perform many maintenance and repair tasks.

Pleasant riding, and thank you for choosing a Honda!



IMPORTANT INFORMATION

COLD TIRE PRESSURES: [UP TO VEHICLE CAPACITY LOAD]		FRONT 225 kPa, 2.25 kg/cm ² , 32 psi
		REAR 280 kPa, 2.80 kg/cm ² , 40 psi
[UP TO 90 kg (200 lbs.) LOAD]		FRONT 225 kPa, 2.25 kg/cm ² , 32 psi
		REAR 225 kPa, 2.25 kg/cm ² , 32 psi
VEHICLE CAPACITY LOAD 161 kg (355 lbs)		
TIRE SIZE: FRONT 100/90-19 57H REAR 130/90-16 67H		

TIRE BRAND	FRONT	REAR
DUNLOP	F11	K627
BRIDGESTONE	L303	G508
MIN. RECOMMENDED CENTER TREAD DEPTH		
FRONT 1.5 mm (0.06 in.) REAR 2.0 mm (0.08 in.)		

Read Owner's manual

THIS MOTORCYCLE
EQUIPPED WITH
TUBELESS TIRES


MOTORCYCLE SAFETY

Read these **WARNING LABELS** before you ride!

- REMEMBER ■ PRESERVE NATURE
■ ALWAYS WEAR A HELMET ■ RIDE SAFELY
■ READ OWNER'S MANUAL CAREFULLY BEFORE RIDING

WARNING: ACCESSORIES AND LOADING

- THE SAFETY, STABILITY AND HANDLING OF THIS MOTORCYCLE MAY BE ADVERSELY AFFECTED BY THE ADDITION OF ACCESSORIES AND CARGO.
- READ AND UNDERSTAND THE WARNING CONTAINED IN THE OWNER'S MANUAL AND THE INSTRUCTIONS IN THE ACCESSORY HANDBOOK BEFORE INSTALLING ANY ACCESSORY.
- THE WEIGHT OF ACCESSORIES AND CARGO MUST BE ADDED TO THE WEIGHT OF THE RIDER AND PASSENGER WHEN DETERMINING IF THE VEHICLE CAPACITY LOAD HAS BEEN EXCEEDED.
- THE CARGO LOAD MUST NOT EXCEED 13.5 KG (30 LBS) UNDER ANY CIRCUMSTANCES.
- THE FITTING OF LARGE FORK-MOUNTED OR LARGE HANDLEBAR-MOUNTED FAIRING IS NOT RECOMMENDED.



SAFE RIDING RULES

WARNING

* *Motorcycle riding requires special efforts on your part to ensure your safety. Know these requirements before you ride.*

1. Always make a pre-ride inspection (page 33) before you ride the motorcycle. You may prevent an accident or equipment damage.
2. Many accidents involve inexperienced riders. Most states require a special motorcycle riding test or license. Make sure you are qualified before you ride. NEVER lend your motorcycle to an inexperienced rider.
3. Many automobile/motorcycle accidents happen because the automobile driver does not "see" the motorcyclist. Make yourself conspicuous to help avoid the accident that wasn't your fault:
 - Wear bright or reflective clothing.
 - Don't ride in another motorist's "blind spot."
4. Obey all federal, state, and local laws and regulations.
 - Excessive speed is a factor in many accidents. Obey the speed limits, and NEVER travel faster than conditions warrant.
 - Signal before you make a turn or lane change. Your size and maneuverability can surprise other motorists.
5. Don't let other motorists surprise you. Use extra caution at intersections, parking lot entrances and exits, and driveways.
6. Keep both hands on the handlebars and both feet on the footpegs while riding. A passenger should hold on to the motorcycle or the operator with both hands and keep both feet on the passenger footpegs.

PROTECTIVE APPAREL

1. Most motorcycle accident fatalities are due to head injuries: ALWAYS wear a helmet. You should also wear a face shield or goggles, boots, gloves, and protective clothing. A passenger needs the same protection.
2. The exhaust system becomes very hot during operation, and it remains hot after operation. Never touch any part of the hot exhaust system. The front frame down tubes may be also become very warm. Wear clothing that fully covers your legs.
3. Do not wear loose clothing which could catch on the control levers, footpegs or wheels.

LOADING AND ACCESSORIES

⚠ WARNING

** To prevent an accident, use extreme care when adding and riding with accessories and cargo. Addition of accessories and cargo can reduce a motorcycle's stability, performance and safe operating speed. Never ride an accessory equipped motorcycle at speeds above 80 mph. And remember that this 80 mph limit may be reduced by installation of non-Honda accessories, improper loading, worn tires and overall motorcycle condition, poor road or weather conditions, etc. These general guidelines may help you decide whether or how to equip your motorcycle, and how to load it safely.*

Loading

The combined weight of the rider, passenger, cargo and additional accessories must not exceed 355 lbs (161 kg), the vehicle capacity load. Cargo weight alone should not exceed 30 lbs.

MODIFICATIONS

⚠ WARNING

** Modification of the motorcycle, or removal of original equipment may render the vehicle unsafe or illegal. Obey all federal, state and local equipment regulations.*

Accessories

Genuine Honda accessories have been specifically designed for and tested on this motorcycle.

Because the factory cannot test all other accessories, you are personally responsible for proper selection, installation and use of accessories. Always follow the guidelines under Loading, and these:

1. Keep cargo and accessory weight low and close to the center of the motorcycle. Load weight equally on both sides to minimize imbalance. As weight is located farther from the motorcycle's center of gravity, handling is proportionally affected.
2. Adjust tire pressure (page 2), front suspension (page 10) and rear suspension (pages 11, 12) to suit load weight and riding conditions.
3. Luggage racks are for lightweight items. Do not carry more than 30 lbs. of cargo on a luggage rack behind the seat. Bulky items too far behind the rider may cause wind turbulence that impairs handling.
4. All cargo and accessories must be secure for stable handling. Recheck cargo security and accessory mounts frequently.
5. Do not attach large, heavy items to the handlebars, front forks, or fender. Unstable handling or slow steering response may result.

1. Carefully inspect the accessory to make sure it does not obscure any lights, reduce ground clearance and banking angle or limit suspension travel, steering travel or control operation.
2. Large fork-mounted fairings or windshields, or poorly designed or improperly mounted fairings can produce aerodynamic forces that cause unstable handling. Do not install fairings that decrease cooling air flow to the engine.
3. Accessories which alter your riding position by moving hands or feet away from controls may increase reaction time in an emergency.

4. Do not add electrical equipment that will exceed the motorcycle's electrical system capacity. A blown fuse could cause a dangerous loss of lights or engine power at night or in traffic.
5. This motorcycle was not designed to pull a sidecar or trailer. Handling may be seriously impaired if so equipped.

TUBELESS TIRES

This motorcycle is equipped with tubeless type tires, valves, and wheel rims. Use only tires marked "TUBELESS" and tubeless valves on rims marked "TUBELESS TIRE APPLICABLE."

Proper air pressure will provide maximum stability, riding comfort and tire life.

Check tire pressures frequently and adjust if necessary (page 2).

NOTE:

- * Tire pressure should be checked when the tires are "cold," before you ride.
- * Tubeless tires have some degree of self-sealing ability if they are punctured, and leakage is often very slow. Inspect very closely for punctures, especially if the tire is not fully inflated.

Check the tires for cuts, imbedded nails or other sharp objects. Check the rims for dents or deformation. If there is any damage, see your authorized Honda dealer for repair, replacement, and balancing.

WARNING

** Improper tire inflation will cause abnormal tread wear and create a safety hazard. Underinflation may result in the tire slipping on, or coming off of the rim.*

** Operation with excessively worn tires is hazardous and will adversely affect traction and handling.*

Replace tires before tread depth at the center of the tire reaches the limit as shown on the tire information label (page 2).

Tire Repair/Replacement:

See your authorized Honda dealer.

WARNING

** The use of tires other than those listed on the tire information label (see page 2) may adversely affect handling.*

** Do not install tube-type tires on tubeless rims. The beads may not seat and the tires could slip on the rims, causing tire deflation.*

** Do not install a tube inside a tubeless tire. Excessive heat build-up may cause the tube to burst resulting in rapid tire deflation.*

** Proper wheel balance is necessary for safe, stable handling of the motorcycle. Do not remove or change any wheel balance weights. When wheel balancing is required, see your authorized Honda dealer. Wheel balancing is required after tire repair or replacement.*

** Do not exceed 50 mph (80 km/h) for the first 24 hours after tire repair, or repair failure and tire deflation may result. Never use a repaired tire for racing or speeds over 80 mph (120 km/h).*

** Replace the tire if the sidewall is punctured or damaged. Sidewall flexing may cause repair failure and tire deflation.*

CAUTION:


** Do not try to remove tubeless tires without special tools and rim protectors. You may damage the rim sealing surface or disfigure the rim.*

See your authorized Honda dealer for tire repair/replacement.

SUSPENSION

Front Suspension

The front suspension of this motorcycle can provide the desired ride under various rider/cargo weights and riding conditions through adjustment of the air pressure within the fork tubes. The recommended pressure under normal riding conditions is 0-6 psi (0-40 kPa, 0-0.4 kg/cm²). Low air pressure settings provide a softer ride and are for light loads and smooth road conditions. High air pressure settings provide a firmer ride and are for heavy loads and rough road conditions. Check and adjust air pressure when the front fork tubes are cold before riding.



(1) Valve caps

1. Place the motorcycle on its center stand. Do not use the side stand or you will get false pressure readings.
2. Remove the front fork air valve caps (1).
3. Check the air pressure using the pressure gauge.

NOTE:

- * Some pressure will be lost when removing the gauge from the valve. Determine the amount of loss and compensate accordingly.
4. Add air to the recommended pressure. Be certain to adjust both front forks to the same air pressure.

NOTE:


- * Do not exceed the recommended air pressure or the ride will be harsh and uncomfortable.

Rear Shock Absorbers

This motorcycle has shock absorbers with two adjustable functions to provide the desired ride with various rider/cargo weights.

The spring adjuster (1) adjusts spring preload for changes in rider/cargo weight.

The rebound damping adjuster (2) adjusts damping to provide the desired ride (soft to firm) under various rider/cargo weights and riding conditions.




(1) Spring adjuster

WARNING

** Be careful not to touch hot mufflers while adjusting the shock absorbers.*

Adjust spring preload first, using the tool kit hook spanner to rotate the spring adjuster (1). Position 1 is for light loads and positions 2 to 5 progressively increase preload for heavier loads.

After adjusting preload, rotate the rebound damping adjuster (2) by the hand to select one of the four positions.



(2) Damping adjuster

NOTE:

- * Be sure to adjust both shock absorbers to the same positions.

Recommended Rear Suspension Adjustment:

REBOUND DAMPING ADJUSTER	SPRING ADJUSTER	CONDITIONS	
		RIDERS/LOAD	RIDING CONDITIONS
1	1 or 2	One	Highways
2	1 or 2	One	Around town
3	2 or 3	One	Winding road
2	3 to 5	One/Two	Highways
3	3 to 5	One/Two or carrying load	Around town
4	4 to 5	One/Two or carrying load	Winding road


T.R.A.C. Anti-dive

The T.R.A.C. anti-dive system (1) controls the amount of damping force which reduces nose-dive during braking and may be adjusted to the rider's choice independent of load or the rider's weight. Located on the left side of the front fork, the adjuster (1) can be set to any one of four positions.

WARNING

- * Do not position the adjuster between the numbered detent adjustment points.

Position	Anti-dive damper force
1	LIGHT ANTI-DIVE
2	MEDIUM
3	HARD
4	MAXIMUM ANTI-DIVE





(1) T.R.A.C. Anti-dive adjuster

DESCRIPTION

PARTS LOCATION


- (1) Fuel tank cap
- (2) Horn button
- (3) Turn signal switch
- (4) Headlight dimmer switch
- (5) Clutch lever
- (6) Choke lever
- (7) Clutch fluid reservoir
- (8) Air valve cap
- (9) Speedometer
- (10) Warning and indicator lights
- (11) Tachometer
- (12) Ignition switch
- (13) Front brake reservoir
- (14) Engine stop switch
- (15) Front brake lever
- (16) Throttle grip
- (17) Starter button
- (18) Air valve cap





- | | | |
|------------------------------------|---------------------|-------------------------------------|
| (1) TRAC anti-dive adjuster | (4) Side stand | (7) Footpeg |
| (2) Fuel valve | (5) Gearshift pedal | (8) Passenger footpeg |
| (3) Engine oil filler cap/dipstick | (6) Center stand | (9) Final drive gear oil filler cap |

16



- | | |
|-----------------------|----------------------|
| (1) Helmet holder | (3) Footpeg |
| (2) Passenger footpeg | (4) Rear brake pedal |


17

SERIAL NUMBERS

The frame and engine serial numbers are required when registering your motorcycle. They may also be required by your dealer when ordering replacement parts. Record the numbers here for your reference.

VIN _____

FRAME NO. _____



(1) VIN



(2) Frame number

18

The engine number (3) is stamped on top of the crankcase.

ENGINE NO. _____




(3) Engine number

COLOR LABEL

The color label (1) is attached to the down tube under the right side cover. It is helpful when ordering replacement parts. Record the color here and code for your reference.

COLOR _____

CODE _____



(1) Color label

19

PARTS FUNCTION

Instruments and Indicators

The indicators and warning lights are grouped around the instruments. Their functions are described in the tables on the following pages.



USA model:

Odometer and tripmeter read in miles.

Canadian model:

Odometer and tripmeter read in kilometers.

- (1) Left turn signal indicator
- (2) Speedometer
- (3) Odometer
- (4) Tripmeter
- (5) Tripmeter reset knob
- (6) Fuel liquid crystal display
- (7) Gear position liquid crystal display
- (8) Tachometer
- (9) Tachometer red zone
- (10) Right turn signal indicator
- (11) High beam indicator
- (12) Neutral indicator
- (13) Tail/stoplight warning light
- (14) Oil pressure warning light




Ref. No.	Description	Function
10.	Right turn signal indicator	Flashes when right turn signal operates.
11.	High beam indicator	Lights when headlight is on high beam.
12.	Neutral indicator	Lights when transmission is in neutral.
13.	Tail/stoplight warning light	Lights when the tail/stoplight bulb is burned out. Should light for a few seconds and go out when the ignition switch is turned ON.
14.	Oil pressure warning light	Lights when engine oil pressure is below normal operating range. Should light when ignition switch is ON and engine is not running. Should go out when engine starts, except for occasional flickering at or near idling speed when the engine is warm. CAUTION: * Running the engine with insufficient oil pressure will cause serious engine damage.

Ref. No.	Description	Function
1.	Left turn signal indicator	Flashes when left turn signal operates.
2.	Speedometer	Shows riding speed.
3.	Odometer	Shows accumulated mileage.
4.	Tripmeter	Shows mileage per trip.
5.	Tripmeter reset knob	Turning the knob in the direction shown (ARROW) resets tripmeter to zero (0).
6.	Fuel liquid crystal display	Shows approximate fuel supply available. (See page 27)
7.	Gear position liquid crystal display	Indicates transmission gear position.
8.	Tachometer	Shows engine rpm.
9.	Tachometer red zone	Never allow the tachometer needle to enter the red zone, even after the engine has been broken in. CAUTION: * The red zone indicates the maximum limits of engine speed and running the engine in the red zone will adversely affect its service life.

Ignition Switch

The ignition switch (1) is below the indicator panel.



Key Position	Function	Key Removal
LOCK (Steering lock)	Steering is locked. Engine and lights cannot be operated.	Key can be removed.
OFF	Engine and lights cannot be operated.	Key can be removed.
ON	Headlight, taillight and instrument lights are on and other lights can be operated. Engine can be started when the engine stop switch is at RUN.	Key cannot be removed.
P (Parking)	For parking the motorcycle near traffic. The taillight is on, but all other lights are off. The engine cannot be started.	Key can be removed.

Engine Stop Switch

The engine stop switch (1) is next to the throttle grip. When the switch is in the RUN position, the engine will operate. When the switch is in the OFF position, the engine will not operate. This switch is intended primarily as a safety or emergency switch and should normally remain in the RUN position.

NOTE:


- * If your motorcycle is stopped with the ignition switch ON and the engine stop switch OFF, the headlight and taillight will still be on, resulting in battery discharge.

Starter Button

The starter button (2) is below the engine stop switch (1).

When the starter button is pressed the starter motor will crank the engine, the headlight will automatically go out, but the taillight will stay on.

See pages 34-35 for starting procedure.



(1) Engine stop switch
(2) Starter button

The three controls next to the left handlebar grip are:

Headlight Dimmer Switch (1)


Select HI for high beam, LO for low beam.

Turn Signal Switch (2)

Move to "L" to signal a left turn, "R" to signal a right turn. Push to turn signal off.

Horn Button (3)

Push the button to sound the horn.




(1) Headlight dimmer switch
(2) Turn signal switch
(3) Horn button

Steering Lock

To lock the steering, turn the handlebars all the way to the left or right and then turn the key (1) to LOCK while pushing in. Remove the key.

WARNING

- * Do not turn the key to LOCK while riding the motorcycle.



(1) Ignition key (A) Push in
(B) Turn to LOCK


Helmet Holder

The helmet holder (1) is on the right side below the seat. Insert the ignition key (2) and turn it clockwise to unlock.

Hang your helmet on the lock and push in the holder pin (3).

WARNING

- * The helmet holder is designed for use while parked. Do not operate the motorcycle with a helmet attached to the holder. The helmet may interfere with the rear wheel, possibly stopping the wheel.



(1) Helmet holder (3) Holder pin
(2) Ignition key

Document Bag

The document bag (1) is attached to the left side cover.

This owner's manual and other documents should be stored in the plastic bag. When washing your motorcycle, be careful not to flood this area with water.



(1) Document bag

Fuel Liquid Crystal Display

The fuel liquid crystal display shows the approximate fuel supply available in a graduated display.

At F (full), there is 13.0 liters (3.4 US gal). When the fuel liquid crystal display flashes at RES (Reserve), it shows that there is about 2.5 Liters (0.7 US gal) left in the tank.

FUEL

Manual Fuel Valve

The manual fuel valve (1) is under the left side of the fuel tank. Set it to ON for normal operation or RES when you start to run out of the main fuel supply. The OFF setting is only for long term storage or servicing of fuel system components.

Automatic Fuel ON-OFF

With the fuel valve set to ON (or RES) fuel flows to the carburetors only when the engine is being started or is running. A diaphragm shuts off fuel flow when the engine is turned off.

Reserve Fuel


When the main fuel supply is gone, turn the fuel valve to RES. The reserve fuel supply is 2.5 l (0.7 US gal) so refill the tank as soon as possible then switch the valve back to ON.

WARNING

- * Know how to operate the fuel valve while riding the motorcycle. You may avoid a sudden stop in traffic.
- * Be careful not to touch any hot engine parts while operating the fuel valve.

NOTE:

- * Do not operate the machine with the fuel valve in the RES position after refueling. You may run out of fuel, with no reserve.




(1) Fuel valve in normal operating position

Fuel Tank

Fuel tank capacity is 13.0 l (3.4 US gal) including 2.5 l (0.7 US gal) in the reserve supply.

To open the fuel tank cap (1), insert the ignition key (2) and turn it clockwise. The cap is hinged and will lift up. Any automotive gasoline with a pump octane number ($\frac{R+M}{2}$) of 86 or higher



(1) Fuel tank cap
(2) Ignition key

or a research octane number of 91 or higher may be used. If "knocking" or "pinging" occurs, try a different brand of gasoline or a higher octane grade.

To close the fuel tank cap, press the cap into the filler neck until it snaps closed; the fuel tank cap locks automatically. Remove the key.

WARNING

- * Gasoline is extremely flammable and is explosive under certain conditions. Refuel in a well-ventilated area with the engine stopped. Do not smoke or allow flames or sparks in the area where the motorcycle is refueled or where gasoline is stored.
- * Do not overfill the tank (there should be no fuel in the filler neck). After refueling, make sure the fuel cap is closed securely.

ENGINE OIL

Engine Oil Level Check


Check the engine oil level each day before riding the motorcycle.

The level must be maintained between the upper (1) and lower (2) level marks on the dipstick (3).

1. Start the engine and let it idle for a few minutes. Make sure the red oil pressure warning light goes off. If the light remains on, stop the engine immediately.
2. Stop the engine and put the motorcycle on its center stand on level ground.
3. After a few minutes, remove the oil filler cap/dipstick (3), wipe it clean, and reinsert the dipstick without screwing it in. The oil level should be between the upper (1) and lower (2) level marks on the dipstick.
4. If required, add the specified oil up to the upper level mark. Do not overfill.
5. Reinstall the oil filler cap/dipstick. Check for oil leaks.

CAUTION:

- * Running the engine with insufficient oil can cause serious engine damage.



(1) Upper level mark (2) Lower level mark (3) Oil filler cap/dipstick

Engine Oil Recommendation

USE HONDA 4-STROKE OIL OR AN EQUIVALENT

Use only high detergent, premium quality motor oil certified to meet or exceed US automobile manufacturers' requirements for Service Classification SE or SF. Motor oils intended for Service SE or SF will show this designation on the container. The use of special oil additives is unnecessary and will only increase operating expenses.


CAUTION:

- * Engine oil is a major factor affecting the performance and service life of the engine. Non-detergent, vegetable, or castor based racing oils, are not recommended.

Recommended Oil Viscosity

SAE 10W-40

Other viscosities shown in the chart below may be used when the average temperature in your riding area is within the indicated range.



FINAL DRIVE OIL

Oil Level Check


Check the final drive oil level when specified by the maintenance schedule (page 55).

1. Place the motorcycle on its center stand on level ground.
2. Remove the oil filler cap (1).
3. Check that the oil level reaches the lower edge of oil cap hole.

NOTE:

- * If the level is low, check for leaks. Pour fresh oil through the oil filler opening until it reaches the lower edge of the opening.

Recommended oil: **HYPOID GEAR OIL**
SAE 80 (Below 5°C/41°F)



(1) Oil filler cap (A) Oil level

STARTING THE ENGINE

WARNING

- * *Never run the engine in a closed area. The exhaust contains poisonous carbon monoxide gas.*

NOTE:

- * Do not use the electric starter for more than 5 seconds at a time. Release the starter button for approximately 10 seconds before pressing it again.
- * The electric starter will work when the transmission is in gear with the clutch disengaged.

PREPARATION

Make sure the transmission is in neutral, the engine stop switch is at RUN and the fuel valve is ON. Insert the key and turn the ignition switch ON.


Check that the red oil pressure warning light comes ON.

STARTING PROCEDURE

To restart a warm engine, follow the procedure for "High Air Temperature."

Normal Air Temperature
10°C–35°C (50°F–95°F)

1. Pull the choke lever (1) back all the way to Fully Open (A).
2. Start the engine, leaving the throttle closed.



(1) Choke lever (A) Fully Open
(B) Fully Closed

OPERATION

PRE-RIDE INSPECTION

WARNING

- * *If the Pre-ride Inspection is not performed, serious damage or an accident may result.*

Inspect your motorcycle every day before you ride it. The items listed here will only take a few minutes, and in the long run they can save time, expense, and possibly your life.

1. Engine oil level—add engine oil if required (pages 30-31). Check for leaks.
2. Fuel level—fill fuel tank when necessary (page 29). Check for leaks.
3. Front and rear brakes—check operation; make sure there is no brake fluid leakage. Adjust free play if necessary (pages 66-69).

4. Tires—Check condition and pressure (pages 8-9).
5. Throttle—check for smooth opening and closing in all steering positions.
6. Lights and horn—check that headlight, tail/stoplight, turn signals, indicators and horn function properly.
7. Engine stop switch—check for proper function (page 24).

Correct any discrepancy before you ride. Contact your authorized Honda dealer for assistance if you cannot correct the problem.

NOTE:

- * Do not open the throttle when starting the engine with the choke open. This will lean the mixture, resulting in hard starting.

CAUTION:

- * *The red oil pressure warning light should go off a few seconds after the engine starts. If the light stays on, stop the engine immediately and check engine oil level. Do not operate the engine with insufficient oil pressure.*
- 3. Immediately after the engine starts, operate the choke lever (1) to keep fast idle at 1,500–2,500 rpm.
- 4. About a half minute after the engine starts, push the choke lever forward all the way to Fully Closed (B).
- 5. If idling is unstable, open the throttle slightly.

High Air Temperature

35°C (95°F) or above

1. Do not use the choke.
2. Open the throttle slightly.
3. Start the engine.

Low Air Temperature

10°C (50°F) or below

1. Follow steps 1–2 under Normal Air Temperature.
2. Warm up the engine by opening and closing the throttle slightly.
3. Continue warming up until the engine runs smoothly and responds to the throttle when the choke lever is at Fully Closed (B).

CAUTION:

- * *Snapping the throttle or fast idling for more than about 5 minutes at normal air temperature may cause exhaust pipe discoloration.*
- * *Extended use of the choke may impair piston and cylinder wall lubrication.*


Flooded Engine

If the engine fails to start after repeated attempts, it may be flooded with excess fuel. To clear a flooded engine, turn the engine stop switch OFF and push the choke lever forward to Fully Closed (B). Open the throttle fully and crank the engine for 5 seconds. Wait 10 seconds, then turn the engine stop switch ON and follow the "High Air Temperature" Starting Procedure.

RIDING

WARNING

- * Review Motorcycle Safety (pages 1-13) before you ride.
- * Make sure the side stand is fully retracted before riding the motorcycle. If the stand is extended, it may interfere with control during a left turn.



Shifting pattern

Proper shifting will provide better fuel economy. When changing gears under normal conditions, use these recommended shift points:

Shifting Up:

From 1st to 2nd:	12 mph (20 km/h)
From 2nd to 3rd:	19 mph (30 km/h)
From 3rd to 4th:	25 mph (40 km/h)
From 4th to 5th:	31 mph (50 km/h)
From 5th to OD:	37 mph (60 km/h)

Shifting Down:

From OD to 5th:	28 mph (45 km/h)
From 5th to 4th:	22 mph (35 km/h)
From 4th to 3rd:	16 mph (25 km/h)

Disengage the clutch when speed drops below 9 mph (15 km/h), when engine roughness is evident, or when engine stalling is imminent; and shift down to 1st gear for acceleration.

BREAK-IN

During initial break-in, newly machined surfaces will be in contact with each other and these surfaces will wear in quickly. Break-in maintenance at 600 miles (1,000 km) is designed to compensate for this initial minor wear. Timely performance of break-in maintenance will ensure optimum service life and performance from the engine.

The general rules are as follows:

1. Do not lug the engine with full throttle at low engine speeds. This rule is applicable not only during break-in but at all times.
2. Vary the engine speed frequently and avoid full throttle. Maximum continuous engine speed during the first 600 miles (1,000 km) must not exceed 5,000 rpm.
3. Increase the maximum continuous engine speed by 2,000 rpm between odometer readings of 600 miles (1,000 km) and 1,000 miles (1,600 km). Drive

briskly, vary speeds frequently and use full throttle for short bursts only. Do not exceed 7,000 rpm.

4. Upon reaching an odometer reading of 1,000 miles (1,600 km), you can subject the motorcycle to full throttle operation.

However, do not exceed 10,000 rpm at any time (tachometer RED ZONE limit).

CAUTION:

- * The red zone indicates the maximum limits of engine speed and running the engine in the red zone will adversely affect its service life.

WARNING

- * Do not downshift when travelling at a speed that would force the engine to overrev in the next lower gear, or cause the rear wheel to lose traction.

CAUTION:

- * Do not shift gears without disengaging the clutch and closing the throttle. The engine and drive train could be damaged by overspeed and shock.
- * Do not tow the motorcycle or coast for long distances while the engine is off. The transmission will not be properly lubricated and damage may result.
- * Do not exceed 8,000 rpm when running the engine without a load. Serious engine damage may result.

NOTE:

- * The battery will not charge while the engine speed is below 1,750 rpm. Avoid idling for prolonged periods, or continuous operation below 1,750 rpm.
- * Be careful when revving the engine or accelerating in 1st or 2nd gear as the engine speed will easily enter the tachometer red zone.

High Altitude Riding

When operating this motorcycle at high altitude, the air-fuel mixture becomes overly rich. Above 6,500 feet (2,000 m) driveability and performance may be reduced and fuel consumption increased. See your authorized Honda dealer for high altitude adjustments.

BRAKING

1. For normal braking, gradually apply both front and rear brakes while downshifting to suit your road speed.
2. For maximum deceleration, close the throttle and apply the front and rear brakes firmly. Disengage the clutch before the motorcycle stops.

WARNING

- * Independent use of only the front or rear brake reduces stopping performance. Extreme braking may cause either wheel to lock, reducing control of the motorcycle.
- * When possible, reduce speed or brake before entering a turn; closing the throttle or braking in mid-turn may cause wheel slip. Wheel slip will reduce control of the motorcycle.

- * When riding in wet or rainy conditions, or on loose surfaces, the ability to maneuver and stop will be reduced. All of your actions should be smooth under these conditions. Sudden acceleration, braking or turning may cause loss of control. For your safety, exercise extreme caution when braking, accelerating or turning.
- * When descending a long, steep grade, use engine compression braking by downshifting, with intermittent use of both brakes. Continuous brake application can overheat the brakes and reduce their effectiveness.

PARKING

1. After stopping the motorcycle, shift the transmission into neutral, turn the ignition switch OFF and remove the key.
2. Use the side or center stand to support the motorcycle while parked.

CAUTION:

- * Park the motorcycle on firm, level ground to prevent overturning.

3. Lock the steering to help prevent theft.

NOTE:

- * When stopping for a short time near traffic at night, the ignition switch may be turned to P and the key removed. This will turn on the taillight to make the motorcycle more visible to traffic. The battery will discharge if the ignition switch is left at P for too long a time.

ANTI-THEFT TIPS

1. Always lock the steering and never leave the key in the ignition switch. This sounds simple but people do forget.
2. Be sure the registration information for your motorcycle is accurate and current.
3. Park your motorcycle in a locked garage whenever possible.
4. Lock the steering (page 25).
5. Put your name, address, and phone number in this Owner's Manual and keep it on your motorcycle at all times. Many times stolen motorcycles are identified by information in the Owner's Manual's which are still with them.

NAME: _____

ADDRESS: _____

PHONE NO.: _____

SPECIAL PROCEDURES

These special procedures are intended to help you out in case of trouble on the road: a flat tire, or a blown fuse. In case of a flat tire, you can remove the entire wheel and take it to a qualified repair facility. Refer to "TIRES" on pages 8–9. Because of the critical nature of wheel attachment, you should proceed to an authorized Honda dealer as soon as possible after repair to verify proper assembly.


WARNING

* Stop the engine and support the motorcycle securely on a level surface before performing these procedures.

TOOL KIT

The tool kit (1) is in the storage compartment behind the left side cover. Some roadside repairs, minor adjustments and parts replacement can be performed with the tools contained in the kit.

- 10 x 12 mm open end wrench
- 14 x 17 mm open end wrench
- Pliers
- 6 mm hex wrench
- Screwdriver grip
- 24 mm box end wrench
- Handle for the box end wrench
- Spark plug wrench
- Feeler gauge 0.7 mm
- Tool bag
- No. 2 Plus minus driver
- Spare fuse (15A)
- Pin spanner




(1) Tool kit

FRONT WHEEL REMOVAL

1. Raise the front wheel off the ground by placing a support block under the engine.
2. Disconnect the speedometer cable (1) by removing the speedometer cable set screw (2).
3. Remove the right caliper assembly from the fork leg by removing the mounting bolts (3).

CAUTION:

* Support the caliper assembly so that it doesn't hang on the hose. Do not twist the brake hose.




- (1) Speedometer cable
(2) Speedometer cable set screw

4. Remove the cap (4) and the front axle holding bolt (5). Unscrew and pull out the front axle (6). Remove the front wheel.

NOTE:


* Do not depress the brake lever when the wheel is off the motorcycle. The caliper pistons will be forced out of the cylinders with subsequent loss of brake fluid. If this occurs, servicing of the brake system will be necessary. See your authorized Honda dealer for this service.



- (3) Caliper mounting bolts (5) Front axle holding bolt (right side)
(4) Front axle holding cap (6) Front axle

Installation Notes:

Install the front wheel between the fork legs and carefully fit the left disc between the brake pads of the left caliper. Insert the axle through the right fork leg and wheel hub, and screw it into the left fork leg. Make sure that the lug (8) on the speedometer gearbox (7) is against the rear of the tang (9) on the left fork leg and that the speedometer cable is connected to the gearbox. Tighten the axle to the specified torque.



- (7) Speedometer gearbox (9) Tang
(8) Lug

Axle torque: 55–65 N·m (5.5–6.5 kg·m, 40–47 ft·lb).

Fit the right caliper over the disc, taking care not to damage the brake pads. Install the caliper mounting bolts and tighten to the specified torque 30–40 N·m (3.0–4.0 kg·m, 22–29 ft·lb).


Measure the clearance (10) between each surface of the brake disc (11) and the caliper holder (12) with a 0.7 mm (0.028 in) feeler gauge (see illustration next page). If gauge (13) inserts easily, tighten the axle holding bolt (5) to the specified torque. Axle holding bolt: 15–25 N·m (1.5–2.5 kg·m, 11–18 ft·lb).

WARNING

* If a torque wrench was not used for installation, see your dealer as soon as possible to verify proper assembly.

If the feeler gauge cannot be inserted easily, pull the forks outward or push inward until the gauge can be inserted and tighten the holding bolt with the gauge inserted. After tightening, remove the gauge.

After installing the wheel, apply the brakes several times, then recheck both discs for caliper holder to disc clearance. Do not operate the motorcycle without adequate clearance.




(10) Clearance
(11) Disc

(12) Caliper holder

48

WARNING


- Failure to provide adequate disc to caliper holder clearance may damage the brake discs and impair braking efficiency.



(13) Feeler gauge

REAR WHEEL REMOVAL


1. Place the motorcycle on its center stand.
2. Remove the rear brake adjusting nut (1) and disconnect the brake rod (2) from the brake arm (3).
3. Disconnect the stopper arm (4) from the brake panel (5) by removing the cotter pin (6), stopper arm nut (7), washer (8) and rubber grommet.



(1) Adjusting nut
(2) Brake rod
(3) Brake arm
(4) Stopper arm
(5) Brake panel

(6) Cotter pin
(7) Stopper arm nut
(8) Washer
(9) Axle holding bolt

4. Remove the axle holding bolt (9).
5. Remove the axle nut (10) while holding the axle at the other end with a wrench.
6. Pull out the axle.
7. Move the wheel to the right to separate it from the final drive gear case.
8. Remove the rear wheel.




(10) Axle nut

49

Installation:

- Before installing the rear wheel, check that the wheel hub and final drive gear splines are coated with lithium-base multipurpose grease with MOS2 additive.
- Reverse the removal procedure.
- Be sure the splines on the wheel hub fit into the final gear case.
- Before tightening the axle holding bolt, tighten the axle nut to prevent misalignment.



- Torque for following bolts:

Axle nut torque:

70–100 N·m
(7.0–10.0 kg-m, 51–72 ft-lb)

Axle holding bolt torque:

20–30 N·m
(2.0–3.0 kg-m, 14–22 ft-lb)

Brake panel stopper bolt torque:

18–25 N·m
(1.8–2.5 kg-m, 13–18 ft-lb)

- Apply the brake several times and check for free wheel rotation when released.

WARNING

- If a torque wrench was not used for installation, see your dealer as soon as possible to verify proper assembly.

CAUTION:


- Always replace used cotter pins with new ones.

FUSE REPLACEMENT

The main fuse (1), located near the battery on the positive lead, is 30A.

The fuse box (3) is under the headlight. The specified fuses (4) are 15A.

When frequent fuse failure occurs, it usually indicates a short circuit or an over-load in the electrical system. See your authorized Honda dealer for repair.




(1) Main fuse (2) Spare main fuse

CAUTION:

- Turn the ignition switch OFF before checking or replacing fuses to prevent accidental short-circuiting.

To replace the main fuse (1), loosen the screws and remove the old fuse. Install the new fuse and tighten the screws securely.



(3) Fuse box (4) Fuses


50

51

To replace fuses in the fuse box (3), remove the fuse box cover. Pull the old fuse out of the clips. Push a new fuse into the clips and install the fuse box cover.

WARNING

- Never use a fuse with a different rating from that specified. Serious damage to the electrical system or a fire may result, causing a dangerous loss of lights or engine power at night or in traffic.




MAINTENANCE

- The U.S. Environmental Protection Agency and California Air Resources Board (CARB) require that your motorcycle comply with applicable exhaust emission standards during its useful life, when operated and maintained according to the instructions provided, and that motorcycles built after January 1, 1983 comply with applicable noise emission standards for one year or 6,000 km (3,730 miles) after the time of sale to the ultimate purchaser, when operated and maintained according to the instructions provided. Compliance with the terms of the Distributor's Warranties for Honda Motorcycle Emission Control Systems is necessary in order to keep the emissions system warranty in effect (USA ONLY).
- When service is required, remember that your authorized Honda dealer knows your motorcycle best and is fully equipped to maintain and repair it. The scheduled maintenance may also be performed by a qualified service facility that normally does this kind of work; or you may perform most of the work yourself if you are mechanically qualified and have the proper tools and service data.
- These instructions are based on the assumption that the motorcycle will be used exclusively for its designed purpose. Sustained high speed operation, or operation in unusually wet or dusty conditions will require more frequent service than specified in the MAINTENANCE SCHEDULE. Consult your authorized Honda dealer for recommendations applicable to your individual needs and use.

WARNING

- If your motorcycle is overturned or involved in a collision, inspect control levers, clutch and brake hoses and reservoirs, calipers, accessories, and other vital parts for damage. Do not ride the motorcycle if damage impairs safe operation. Have your Honda dealer inspect the major components including frame, suspension and steering parts, for misalignment and damage that you may not be able to detect.
- Stop the engine and support the motorcycle securely on a level surface before performing any maintenance.
- Use new, genuine Honda parts or their equivalent for maintenance and repair. Parts which are not of equivalent quality may impair the safety of your motorcycle and the effective operation of the emission control systems.

The Vehicle Emission Control Information label is attached to the inside of the right side cover. (USA ONLY).
The Vacuum Hose Routing Diagram label (2) is attached to the inside of the right side cover. (CALIFORNIA ONLY).



(1) Vehicle Emission Control Information label
(2) Vacuum Hose Routing Diagram label

MAINTENANCE SCHEDULE

Perform the Pre-ride Inspection (page 33) at each scheduled maintenance period.

I: INSPECT AND CLEAN, ADJUST, LUBRICATE OR REPLACE IF NECESSARY

C: CLEAN R: REPLACE A: ADJUST

FREQUENCY		WHICHEVER COMES FIRST ↓ EVERY	ODOMETER READING [NOTE (4)]								Refer to
			600 mi (1,000 km)	4,000 mi (6,400 km)	8,000 mi (12,800 km)	12,000 mi (19,200 km)	16,000 mi (25,600 km)	20,000 mi (32,000 km)	24,000 mi (38,400 km)		
ITEMS											
EMISSION RELATED ITEMS	* FUEL LINES		I	I	I	I	I	I			
	* FUEL STRAINER		C	C	C	C	C	C			
	* THROTTLE OPERATION		I	I	I	I	I	I			
	* CARBURETOR-CHOKE		I	I	I	I	I	I			
	AIR CLEANER	NOTE (1)		C	R	C	R	C	R	Page 61	
	CRANKCASE BREATHER	NOTE (2)		C	C	C	C	C	C	Page 63	
	SPARK PLUGS			R	R	R	R	R	R	Page 60	
	ENGINE OIL	YEAR	R	R	R	R	R	R	R	Page 58	
	ENGINE OIL FILTER	YEAR	R	R	R	R	R	R	R	Page 59	
	* CARBURETOR- SYNCHRONIZATION		I	I	I	I	I	I	I		
	* CARBURETOR-IDLE SPEED		I	I	I	I	I	I	I	Page 62	
	* EVAPORATIVE EMISSION CONTROL SYSTEM	NOTE (3)			I		I		I		

ITEMS	FREQUENCY	WHICHEVER COMES FIRST ↓	ODOMETER READING [NOTE(4)]							
			600 mi (1,000 km)	4,000 mi (6,400 km)	8,000 mi (12,800 km)	12,000 mi (19,200 km)	16,000 mi (25,600 km)	20,000 mi (32,000 km)	24,000 mi (38,400 km)	Refer to
* FINAL DRIVE OIL		EVERY								Page 64
BATTERY	MONTH		I	I	I	I	I	I	I	Pages 71-72
BRAKE FLUID (FRONT)	MONTH 1		I	I	I	I	I	I	I	Pages 66-67
BRAKE SHOE/PAD WEAR	2 YEARS *R		I	I	I	I	I	I	I	Pages 67, 69
BRAKE SYSTEM			I	I	I	I	I	I	I	Pages 66-69
* BRAKE LIGHT SWITCH			I	I	I	I	I	I	I	
* HEADLIGHT AIM			I	I	I	I	I	I	I	
CLUTCH FLUID	MONTH 1		I	I	I	I	I	I	I	Page 65
CLUTCH SYSTEM	2 YEARS *R		I	I	I	I	I	I	I	Page 65
SIDE STAND			I	I	I	I	I	I	I	Page 70
* SUSPENSION			I	I	I	I	I	I	I	
* NUTS, BOLTS, FASTENERS			I	I	I	I	I	I	I	
** WHEELS			I	I	I	I	I	I	I	
** STEERING HEAD BEARING			I	I	I	I	I	I	I	

** IN THE INTEREST OF SAFETY, WE RECOMMEND THESE ITEMS BE SERVICED ONLY BY AN AUTHORIZED HONDA DEALER.

* SHOULD BE SERVICED BY AN AUTHORIZED HONDA DEALER, UNLESS THE OWNER HAS PROPER TOOLS AND SERVICE DATA AND IS MECHANICALLY QUALIFIED. REFER TO THE OFFICIAL HONDA SHOP MANUAL.

- NOTES:
- (1) Service more frequently when riding in dusty areas.
 - (2) Service more frequently when riding in rain, or at full throttle.
 - (3) California type only.
 - (4) For higher odometer reading, repeat at the frequency interval established here.

MAINTENANCE RECORD

Miles	Performed By	Odometer	Date
600			
4,000			
8,000	CK	10,400	7-22-05
12,000			
16,000			
20,000			
24,000			

- Make sure whoever performs the maintenance completes this record. All scheduled maintenance, including the 600 miles (1,000 km) break-in maintenance, is considered a normal owner operating cost and will be charged for by your dealer.
- Detailed receipts verifying the performance of required maintenance should be retained. These receipts should be transferred with the motorcycle to the new owner if the motorcycle is sold.


Engine Oil/Engine Oil Filter

Engine Oil

Engine oil quality is the chief factor affecting engine service life. Change the engine oil when specified by the maintenance schedule.

NOTE:

- Change engine oil with the engine warm and the motorcycle on its center stand to assure complete and rapid draining.
1. To drain the oil, remove the oil filler cap/dipstick (3), crankcase drain plug (4) and oil filter cover (7).



(1) Upper level mark (3) Oil filler cap/dipstick

2. After the oil has completely drained, check that the sealing washer (5) on the oil drain plug is in good condition and install the drain plug.


Drain Plug Torque:

30–40 N·m (3.0–4.0 kg-m,
22–29 ft-lb)

3. Check that the oil filter bolt (6) and cover O-rings are in good condition and install the cover.


Oil Filter Bolt Torque:

28–32 N·m (2.8–3.2 kg-m,
20–23 ft-lb)



(4) Oil drain plug (5) Sealing washer

4. Fill the crankcase with approximately 3.2 liters (3.4 US qt) of the recommended grade oil.
5. Install the oil filler cap/dipstick (3).
6. Start the engine and let it idle for 2–3 minutes.
7. Stop the engine and check that the oil level is at the upper level mark (1) on the dipstick. Make sure there are no oil leaks.




(6) Oil filter bolt (7) Oil filter cover

Engine Oil Filter

NOTE:

- Change the filter after draining the engine oil.
1. Remove the oil filter element (1) from the cover.
 2. Check that the O-rings (2) on the oil filter bolt and cover are in good condition.
 3. Insert a new oil filter element. Check that all parts are installed as shown. Install the oil filter cover.
Oil Filter Bolt Torque: 28–32 N·m (2.8–3.2 kg-m, 20–23 ft-lb)
 4. Perform steps 4–7 of Engine Oil Change.



(1) Oil filter element (2) O-rings

SPARK PLUGS

Recommended plugs:

Standard:

DPR8EA-9 (NGK) or
X24EPR-U9 (ND)

For cold climate: (Below 5°C/41°F)

DPR7EA-9 (NGK) or
X22EPR-U9 (ND)

For extended high speed riding:


DPR9EA-9 (NGK) or
X27EPR-U9 (ND)

1. Disconnect the spark plug caps.
2. Clean any dirt from around the spark plug bases.
3. Remove and discard the spark plugs.
4. Make sure the new spark plug gap (1) is 0.8–0.9 mm (0.031–0.035 in) using a wire-type feeler gauge. If adjustment is necessary, bend the side electrode (2) carefully.
5. With the plug washers attached, thread the new spark plugs in by hand to prevent cross-threading.

6. Tighten the spark plugs 1/2 turn with a spark plug wrench to compress the washer.
7. Reinstall the spark plug caps.

CAUTION:

- * The spark plug must be securely tightened. An improperly tightened plug can become very hot and possibly damage the engine.
- * Never use a spark plug with an improper heat range.




(1) Spark plug gap (2) Side electrode

AIR CLEANER

The air cleaners should be serviced at regular intervals (page 55). When riding in dusty areas, more frequent service may be necessary.


1. Remove the right side cover and wire band.
2. Remove the air cleaner cover (1) by removing the three screws (2). Pull out the set spring (3) and element (4).
3. Clean the element by tapping it lightly to loosen dust. Blow away the remain-



(1) Air cleaner cover (2) Screws

ing dust by applying compressed air to the outside of the element. Replace the element if it is excessively dirty, torn or damaged.

4. Reinstall the element, set spring and air cleaner cover, and wire band.



(3) Set spring (4) Element

IDLE SPEED


The idle speed adjustment procedure given here should only be used when changes in altitude affect normal idle speed as set by your dealer. See your authorized Honda dealer for regularly scheduled carburetor adjustments, including individual carburetor adjustment and synchronization.

NOTE:

- * Inspect and adjust carburetor idle speed after all other engine adjustments are within specifications.
- * The engine must be warm for accurate idle speed adjustment. Ten minutes of stop-and-go riding is sufficient.

1. Warm up the engine, shift to neutral and place the motorcycle on its center stand.
2. Adjust idle speed with the throttle stop screw (1).

Idle Speed: 1,100 ± 100 rpm
(In neutral)




(1) Throttle stop screw (A) Increase (B) Decrease

CRANKCASE BREATHER

1. Remove the drain plug (1) from the tube and drain deposits.
2. Reinstall the drain plug.

NOTE:

- * Service more frequently when ridden in rain, at full throttle. Service if the deposit level can be seen in the transparent section of the drain tube.



(1) Drain plug

FINAL DRIVE OIL

Change the oil when specified by the maintenance schedule.

NOTE:

* Change the oil with the final drive warm and the motorcycle on its center stand to assure complete and rapid draining.

1. To drain the oil, remove the oil filler cap (1) and drain plug (2).

2. After the oil has completely drained, check that the sealing washer (3) on the drain plug is in good condition and install the drain plug.

Drain Plug Torque:


10–14 N·m

(1.0–1.4 kg·m, 7–10 ft·lb)

3. Fill the final drive with approximately 150 cc (4.9 oz) of the recommended oil. Make sure the recommended oil is filled up to the lower edge of the inspection hole (A).

4. Install the oil filler cap.

Recommended oil: **HYPOID GEAR OIL SAE80 (Below 5°C/41°F)**



(1) Oil filler cap
(2) Oil drain plug

(3) Sealing washer
(A) Inspection hole

CLUTCH


This motorcycle has a hydraulically activated clutch. There are no adjustments to perform but the clutch system must be inspected periodically for fluid level and leakage. If the control lever free play becomes excessive and the motorcycle creeps or stalls when shifted into gear, or if the clutch slips, causing acceleration to lag behind engine speed, there is probably air in the clutch system and it must be bled out. See your authorized Honda dealer for this service.

Fluid Level:

Check that the fluid level is upper the lower level mark (3). If the fluid level is near the lower level mark, it indicates the fluid is leakage. See your authorized Honda dealer for repairment.

Other Checks:

Make sure there are no fluid leaks. Check for deterioration or cracks in the hose and fittings.



(1) Screws
(2) Reservoir cover

(3) Lower level mark
(4) Upper level mark

FRONT BRAKE

This motorcycle has hydraulic disc front brakes. As the brake pads wear, brake fluid level drops, automatically compensating for wear.

There are no adjustments to perform, but fluid level and pad wear must be inspected periodically. The system must be inspected frequently to ensure there are no fluid leaks.

If the brake lever free travel becomes excessive and the brake pads are not worn beyond the recommended limit there is probably air in the brake system and it must be bled out. See your authorized Honda dealer for this service.

Brake Fluid Level:


WARNING

* Brake fluid may cause irritation. Avoid contact with skin or eyes. In case of contact, flush thoroughly with water and call a doctor if your eyes were exposed.

Whenever the level is near the lower level mark (3) on the reservoir, fluid must be added. Remove the screws (1), reservoir cover (2), separator and diaphragm. Fill the reservoir with DOT 3 or DOT 4 BRAKE FLUID from a sealed container up to the upper level mark (4). Reinstall the diaphragm, separator, and cover (2). Tighten the screws (1) securely.

CAUTION:

* When adding brake fluid be sure the reservoir is horizontal before the cover is removed or brake fluid may spill out.



(1) Screws
(2) Reservoir cover

(3) Lower level mark
(4) Upper level mark

- * Use only DOT 3 or DOT 4 brake fluid from a sealed container.
- * Handle brake fluid with care because it can damage paint and instrument lenses.
- * Never allow contaminants (dirt, water, etc.) to enter the brake fluid reservoir.

Brake Pads:

Brake pad wear will depend upon the severity of usage, type of riding, and condition of the roads. The pads will wear faster on dirty and wet roads. Inspect the pads visually from the direction indicated by the arrow (1) during all regular service intervals to determine the pad wear. If either pad wears to the line (3), both pads must be replaced as a set.

Other Checks:

Make sure there are no fluid leaks. Check for deterioration or cracks in the hoses and fittings.




(1) Arrow
(2) Brake disc

(3) Line

REAR BRAKE

Adjustment:

1. Place the motorcycle on its center stand.
2. The stopper bolt (1) is provided to allow adjustment of the pedal height. To adjust the pedal height, loosen the lock nut (2) and turn the stopper bolt. Tighten the lock nut.
3. Measure the distance the rear brake pedal (3) moves before the brake starts to take hold.




(1) Stopper bolt (2) Lock nut
(3) Rear brake pedal

68

Free play should be 20–30 mm (3/4–1-1/4 in). If adjustment is necessary, turn the rear brake adjusting nut (4).

NOTE:

- Make sure the cut-out on the adjusting nut is seated on the brake arm pin.
- If proper adjustment cannot be obtained by this method, see your authorized Honda dealer.



(4) Adjusting nut (A) Decrease free play
(B) Increase free play

4. Apply the brake several times and check for free wheel rotation when released.

Other Checks:

Make sure the brake rod, brake arm, spring and fasteners are in good condition.

Wear Indicator:

When the brake is applied, an arrow (1) attached to the brake arm (2) moves toward a reference mark (3) on the brake panel (4).

If the arrow aligns with the reference mark on full application of the brake, the brake shoes must be replaced.

See your authorized Honda dealer for this service.




(1) Arrow (2) Brake arm
(3) Reference mark (4) Brake panel

69

SIDE STAND

Check the rubber pad for deterioration and wear. Replace if wear extends to the wear line (1) as shown. Check the side stand spring for damage and loss of tension, and the side stand assembly for freedom of movement. See your authorized Honda dealer for replacement.



(1) Wear line

70

BATTERY

If the motorcycle is operated with insufficient battery electrolyte, sulfation and battery plate damage will occur.

If rapid loss of electrolyte is experienced, or if your battery seems to be weak, causing slow starting or other electrical problems, see your authorized Honda dealer.

Battery electrolyte:

The battery (1) is behind the right side cover. Remove the side cover. Check the electrolyte level.

The electrolyte level must be maintained between the upper (2) and lower (3) level marks on the side of the battery. If the electrolyte level is low, remove the battery filler caps (4).


Carefully add distilled water to the upper level mark, using a small syringe or plastic funnel.

CAUTION:

- When checking the battery electrolyte level or adding distilled water, make sure the breather tube (5) is connected to the battery breather outlet.

NOTE:

- Use only distilled water in the battery. Tap water may shorten the service life of the battery.



(1) Battery (2) Upper level mark (3) Lower level mark
(4) Filler caps (5) Breather tube


71

WARNING

- * The battery contains sulfuric acid. Avoid contact with skin, eyes or clothing. Antidote: EXTERNAL-Flush with water. INTERNAL-Drink large quantities of water or milk. Follow with milk of magnesia, beaten egg or vegetable oil. Call physician immediately. Eyes: Flush with water and get prompt medical attention.
- * Batteries produce explosive gases. Keep sparks, flames and cigarettes away. Ventilate when charging or using in enclosed space. Always shield eyes when working near batteries.
- * KEEP OUT OF REACH OF CHILDREN.

CAUTION:

- * The battery breather tube must be routed as shown on the label. Do not bend or twist the breather tube. A bent or kinked breather tube may pressurize the battery and damage its case.



STORAGE GUIDE

STORAGE

Extended storage, such as for winter, requires that you take certain steps to reduce the effects of deterioration from non-use of the motorcycle. In addition, necessary repairs should be made BEFORE storing the motorcycle; otherwise, these repairs may be forgotten by the time the motorcycle is removed from storage.

1. Change the engine oil and filter.
2. Drain the fuel tank and carburetors. Spray the inside of the tank with an aerosol rust-inhibiting oil. Reinstall the fuel cap on the tank.

WARNING

- * Gasoline is flammable and is explosive under certain conditions. Do not smoke or allow flames or sparks near the equipment while draining fuel.

CLEANING

Clean your motorcycle regularly to protect the surface finishes and inspect for damage, wear, and oil, hydraulic fluid seepage.

CAUTION:

- * Avoid spraying high pressure water (typical in coin-operated car washes) at the following areas:

Wheel Hubs	Ignition Switch
Carburetors	Brake Master Cylinder
Instruments	Clutch Master Cylinder
Handlebar switches	Muffler Outlets
	Under Fuel Tank
	Under Seat

1. After cleaning, rinse the motorcycle thoroughly with plenty of clean water. Strong detergent residue can corrode alloy parts.
2. Dry the motorcycle, start the engine, and let it run for several minutes.

3. Test the brakes before riding the motorcycle. Several applications may be necessary to restore normal braking performance.

WARNING

- * Braking performance may be impaired immediately after washing the motorcycle.

Aluminum Wheel Care

Aluminum corrodes when it comes in contact with dust, mud, road salt, etc. After riding, clean the wheels with a wet sponge and mild detergent, then rinse well with water and wipe dry with a clean cloth.

CAUTION:

- * Do not use steel wool or a cleaner containing abrasives or compounds to clean the wheels, as they can cause damage.
- * Do not ride over a curb or rub the wheel against an obstacle, as wheel damage may result.

REMOVAL FROM STORAGE

4. Remove the battery. Store in an area protected from freezing temperatures and direct sunlight. Check the electrolyte level and slow charge the battery once a month.
5. Wash and dry the motorcycle. Wax all painted surfaces. Coat chrome with rust-inhibiting oil.
6. Inflate the tires to their recommended pressures. Place the motorcycle on blocks to raise both tires off the ground.
7. Cover the motorcycle (don't use plastic or other coated materials) and store in an unheated area, free of dampness with a minimum of daily temperature variation. Do not store the motorcycle in direct sunlight.

1. Uncover and clean the motorcycle. Change the engine oil if more than 4 months have passed since the start of storage.
2. Check the battery electrolyte level and charge the battery as required. Install the battery.
3. Drain any excess aerosol rust-inhibiting oil from the fuel tank. Fill the fuel tank with fresh gasoline.
4. Check the final drive oil, adding the recommended gear oil if necessary. Change the final drive oil as specified by the Maintenance Schedule. Perform all Pre-ride Inspection checks (page 33). Test ride the motorcycle at low speeds in a safe riding area away from traffic.

EMISSION CONTROL SYSTEM (U S A ONLY)

• Source of Emissions

The combustion process produces carbon monoxide and hydrocarbons. Control of hydrocarbons is very important because under certain conditions, they react to form photochemical smog when subjected to sunlight. Carbon monoxide does not react in the same way, but it is toxic.

Honda Motor Co., Ltd. utilizes lean carburetor settings and other systems to reduce carbon monoxide and hydrocarbons.

• Exhaust Emission Control System

The exhaust emission control system is composed of lean carburetor settings, and no adjustments should be made except idle speed adjustment with the throttle stop screw. The exhaust emission control system is separate from the crankcase emission control system.

• Noise Emission Control System

TAMPERING WITH THE NOISE CONTROL SYSTEM IS PROHIBITED: Federal law prohibits the following acts or the causing thereof: (1) The removal or rendering inoperative by any person, other than for purposes of maintenance, repair, or replacement, of any device or element of design incorporated into any new vehicle for the purpose of noise control prior to its sale or delivery to the ultimate purchaser or while it is in use; or (2) the use of the vehicle after such device or element of design has been removed or rendered inoperative by any person.

AMONG THOSE ACTS PRESUMED TO CONSTITUTE TAMPERING ARE THE ACTS LISTED BELOW:

1. Removal of, or puncturing the muffler, baffles, header pipes or any other component which conducts exhaust gases.
2. Removal of, or puncturing of any part of the intake system.
3. Lack of proper maintenance.
4. Replacing any moving parts of the vehicle, or parts of the exhaust or intake system, with parts other than those specified by the manufacturer.

• Evaporative Emission Control System (California only)

This motorcycle complies with the California Air Resources Board (CARB) requirements for evaporative emission regulations. Fuel vapor from the fuel tank is directed into the charcoal canister where it is absorbed and stored while the engine is stopped. When the engine is running and the purge control diaphragm valve is open, fuel vapor in the charcoal canister is drawn into the engine through the carburetor.

• Crankcase Emission Control System

The engine is equipped with a closed crankcase system to prevent discharging crankcase emissions into the atmosphere.

Blow-by gas is returned to the combustion chamber through the air cleaner and the carburetor.

• Problems Which May Affect Motorcycle Emissions

If you are aware of any of the following symptoms, have the motorcycle inspected and repaired by your authorized Honda Motorcycle Dealer.

Symptoms:

1. Hard starting or stalling after starting
2. Rough idle
3. Misfiring or backfiring during acceleration
4. After-burning (backfiring)
5. Poor performance (driveability) and poor fuel economy


CONSUMER INFORMATION (USA ONLY)

VEHICLE STOPPING DISTANCE

This table indicates braking performance that can be met or exceeded by the vehicles to which it applies, under different conditions of loading.

The information presented represents results obtainable by skilled riders under controlled road and vehicle conditions, and the information may not be correct under other conditions.

Fully operational service brake



SPECIFICATIONS

Item	
DIMENSIONS	
Overall length	2,140 mm (84.3 in)
Overall width	805 mm (31.7 in)
Overall height	1,145 mm (45.1 in)
Wheelbase	1,460 mm (57.5 in)
WEIGHT	
Dry weight	197 kg (434 lbs) * 198 kg (436 lbs)
CAPACITIES	
Engine oil	3.2 l (3.5 US qt) After draining
Final drive gear oil	150 cc (4.9 oz)
Fuel tank	13 l (3.4 US gal)
Fuel reserve tank	2.5 l (0.7 US gal)
Operator and one passenger	
Passenger capacity	161 kg (355 lbs)
Vehicle capacity load	
ENGINE	
Bore and stroke	60 x 58 (2.362 x 2.283 in)
Compression ratio	9.5 : 1
Displacement	655 cc (40.0 cu.in)

* California only

Item	
Spark plug	
Standard	X24EPR-U9 (ND) or DPR8EA-9 (NGK)
For cold climate: (Below 5°C, 41°F)	X22EPR-U9 (ND) or DPR7EA-9 (NGK)
For extended high speed riding	X27EPR-U9 (ND) or DPR9EA-9 (NGK)
Spark plug gap	0.8–0.9 mm (0.031–0.035 in)
Idle speed	1,100 ± 100 rpm

Item	
CHASSIS AND SUSPENSION	
Caster	61°30'
Trail	98 mm (3.9 in)
Tire size, front	100/90-19-57H
Tire size, rear	130/90-16-67H
POWER TRANSMISSION	
Primary reduction	1.704
Final reduction	3.477
Gear ratio, 1st	2.769 : 1
2nd	1.850 : 1
3rd	1.428 : 1
4th	1.153 : 1
5th	0.966 : 1
OD	0.821 : 1

Item	
ELECTRICAL	
Battery	12V-12AH
Alternator	280W/5,000 rpm
LIGHTS	
Headlight (HIGH/LOW)	12V-60/55W H4 BULB (Phillips 12342/99 or equivalent)
Tail/stoplight	12V-3/32 cp SAE NO. 1157
Turn signal	12V-32 cp SAE NO. 1034 FRONT 1034 REAR 1034 SAE NO. 57
Instrument	12V-2 cp
Neutral indicator	12V-2CP
Turn signal indicator	12V-2CP
High beam indicator	12V-2CP
Oil pressure warning light	12V-2CP
Position	12V-3 cp SAE NO. 1157
FUSE	15A (Headlight, taillight and instrument light) 30A (Main fuse)

MEMO

WARRANTY SERVICE

Owner Satisfaction

Your satisfaction and goodwill are important to your dealer and to us. All Honda warranty details are explained in the Distributor's Limited Warranty. Normally, any problems with the product will be handled by your dealer's service department. Sometimes, however, in spite of the best intentions of all concerned, misunderstandings can occur. If your problem has not been handled to your satisfaction, we suggest you take the following action:

- Discuss your problem with a member of dealership management. Often complaints can be quickly resolved at that level. If the problem has already been reviewed with the Service Manager, contact the owner of the dealership or the General Manager.
- If your problem still has not been resolved to your satisfaction, contact the Customer Relations Department at the regional office of American Honda Motor Co., Inc. in your area. Regional office locations are shown on the following page. We will need the following information in order to assist you:
 - Your name, address, and telephone number
 - Product model and serial number
 - Date of purchase
 - Dealer name and address
 - Nature of the problem

After reviewing all the facts involved, you will be advised of what action can be taken. Please bear in mind that your problem will likely be resolved at the dealership, using the dealer's facilities, equipment, and personnel, so it is very important that your initial contact be with the dealer.

Your purchase of a Honda product is greatly appreciated by both the dealer and American Honda Motor Co., Inc. We want to assist you in every way possible to assure your complete satisfaction with your purchase.

Regional Office Location

NORTHWEST REGIONAL OFFICE
(includes Alaska)
American Honda Motor Co., Inc.
Customer Relations Department
P.O. Box 30285
Portland, Oregon 97220
Telephone: (503) 255-1180

MIDWEST REGIONAL OFFICE
American Honda Motor Co., Inc.
Customer Relations Department
P.O. Box 22
Greendale, Wisconsin 53129
Telephone: (414) 421-9300

NORTHEAST REGIONAL OFFICE
American Honda Motor Co., Inc.
Customer Relations Department
P.O. Box 749
Moorestown, New Jersey 08067
Telephone: (609) 778-1100

WESTERN REGIONAL OFFICE
(includes Hawaii)
American Honda Motor Co., Inc.
Customer Relations Department
P.O. Box 420
Gardena, California 90247
Telephone: (213) 904-2524

SOUTHWEST REGIONAL OFFICE
American Honda Motor Co., Inc.
Customer Relations Department
P.O. Box 8406
Irving, Texas 75062
Telephone: (214) 258-8883

SOUTHEAST REGIONAL OFFICE
(includes Puerto Rico)
American Honda Motor Co., Inc.
Customer Relations Department
6584 Jimmy Carter Boulevard
Norcross, Georgia 30071
Telephone: (404) 448-1992

